

Light Fabric Transfers Use & Care Instructions

BEFORE YOU START, PLEASE READ

There are a few very important things you should keep in mind when using Light Fabric Transfers:

Fabric Choice

Light Fabric Transfers should only be used with white/light-colored 100% cotton or cotton/poly blend fabric.

Note: using colored fabric will result in the fabric color showing through the design. The best fabric color choices are white, off-white, and cream.

Timing

Make sure you pay close attention to your iron time. If you don't iron for the right amount of time, the transfer will not adhere properly.

Heat and Pressure

The proper heat setting and amount of pressure is important. If your iron is not hot enough or you don't apply enough pressure, the transfer will not adhere properly.

For best results, read all instructions before proceeding

What you will need

- New white/light-colored 100% cotton or cotton/poly blend fabric
- Pillowcase (to be placed between your fabric and the ironing surface)
- Household iron (for best results, check the bottom for a smooth, flat surface to ensure 100% coverage when ironing)
- Smooth, hard ironing surface such as a countertop or tabletop **(DO NOT use glass or an ironing board)**

Preparing your fabric


1. Heat your iron to the maximum/linen setting. **DO NOT use the steam setting.**
2. Place the pillowcase onto your ironing surface. **DO NOT use glass or an ironing board.** Iron out any wrinkles and smooth it over with your hands so that it is smooth and flat.
3. Lay your fabric on top of the pillowcase. Iron out any wrinkles and smooth it over with your hands so that the print area is smooth and flat. Allow fabric to cool. *Tip: Before applying your transfer, use a lint roller to remove any lint from fabric.*

Proper heat, firm pressure and ironing time are ALL required to get a successful transfer. The more pressure applied when ironing, the better your results. Ensure iron remains ON during the entire transfer process as some irons have an auto-off feature.


Applying your transfer - *adult supervision is always recommended*

NOTE: The Light Fabric Transfer process is different from the Dark Fabric Transfer process. Carefully read and follow ALL of the instructions below.

- 1 Cut out your design leaving a $\frac{1}{8}$ " border around your image.



- 2 Carefully place the transfer onto your fabric in the desired location, image side down.



- 3 Iron the backing paper with firm pressure, **using both hands** in a straight, non-stop motion: top-to-bottom then side-to-side. *Note: Be sure you cover the entire design, including the edges. Keep the iron moving to prevent scorching and yellowing.*



OPTIMAL IRONING TIMES:


1 minute - designs that take up $\frac{1}{4}$ of the transfer sheet

1 $\frac{1}{2}$ minutes - designs that take up $\frac{1}{2}$ of the transfer sheet


2 minutes - designs that take up the full transfer sheet

If using an iron with a sole plate (the bottom) with recessed channels, extra ironing up to 1 additional minute may be needed.

Note: for Heat Press instructions see reverse side.



- 4 Allow fabric to cool, then peel the backing paper. Hold the fabric in place with one hand. Smoothly and evenly peel away with the other hand.



- 5 Sit back and admire your beautiful creation.



Heat Press Instructions

1. Preheat press to:
350-375°F (or 176-190°C) for 100% - 50% cotton blends.
250°F (or 121°C) for fabrics less than 50% cotton.
2. Press fabric for 3-5 seconds to release moisture and remove wrinkles.
3. Place printed transfer onto the fabric with the image side down.
4. Set to medium pressure for best results.
5. Press for about 20 seconds.
6. Wait 20 seconds, then peel the backing paper from the transfer using a smooth, even motion.

Care and Handling

Washing

- Wait at least 24 hours before washing, wearing or using to allow the ink to completely dry.
- To prolong the vibrancy of the transfer, wash the fabric inside out in cold water.
- Do not use bleach when washing.
- Remove as soon as the wash cycle is complete.

Drying

- Turn fabric inside out, tumble dry on the lowest setting, or lay flat to dry with the transfer facing outwards.

Ironing

- If ironing fabric is desired, do not iron directly on the transfer.

